



# EMG Sensors

Luke Cohen  
Ian Fan  
Yuguo Sheng





# **EMG: Origin and Characteristics**

# EMG Definition




Electromyography (EMG): study of myoelectric signals.

“Myo-”: Muscle



# Generation of EMG


When the membrane potential is depolarized beyond threshold, **action potential** is generated, and travels along the axon. Similar action potential also travels along the muscle fiber



# Detect EMG with differential amplifier



Cannot probe individual neuron activity

⇒ Surface EMG: stick electrodes to the skin, amplifies the difference





# Detect EMG with differential amplifier

Unipolar action potential signal becomes bipolar signal after differential amplifier.  
Signals from multiple muscle fibres superpose together




# Superposition and EMG Characteristics

Recorded EMG signals waveforms are **random** and **non-reproducible**,  
But the difference between active and rest are significant.



# Magnitude and Spectrum of EMG




Raw surface EMG:  
+/- 5000  $\mu V$  (athletes)

Frequency:  
6~500Hz,  
majority of power in:  
20~150Hz



# Setup to work with EMG signals






# **Inside EMG Sensor: Amplification and signal processing**


# EMG-Amplification

- Electrodes attached to EMG-amplifier
- Acts as differential amplifier
  - Detects differences between electrodes
- Cancel external noise at both electrodes
  - “Common mode” signals
  - E.g. 60Hz power noise
- Preamp near electrodes to buffer original signal




# Bandpass filter

- EMG signal generally between 20 Hz and 250 Hz
- Frequency range should start from 10 Hz highpass to 500 Hz lowpass




# A/D Conversion

- Signal must be converted from analog to digital
- Sampling rate: 1000Hz
  - Nyquist Theorem
- Signal after filter: 10~500Hz




# Signal Processing

- Full wave rectification
  - Allows for average, max, and area measurements
- Smoothing
  - Moving average vs. Root Mean Square
- Digital filtering
  - Generally not needed with newer tech
- Amplitude Normalization
  - Use of MVC-normalization (Maximum Voluntary Contraction) is most common




Rectification



Smoothing


# Signal Processing




Blue:  
Raw EMG  
Red:  
Processed Signal

# Signal Baseline Quality Inspection

- Power hum
  - Make sure ground is connected and clean
- Baseline offset
  - Offset correction/calibration required shortly before recording of data
- Baseline shift
  - Proper electrode/cable fixation
  - Good skin preparation



Power hum




Baseline shift






# Work with EMG Sensor: MyoWare

# MyoWare: Built-in signal processing



# Demo Video

---



# MyoWare EMG Sensor




Parameter	Min	TYP	Max
Supply Voltage	+2.9V	+3.3V or +5V	+5.7V
Adjustable Gain Potentiometer	0.01 $\Omega$	50 k $\Omega$	100 k $\Omega$
Output Signal Voltage			
EMG Envelope	0V	--	+Vs
Raw EMG (centered about +Vs/2)	0V	--	+Vs
Input Impedance	--	110 G $\Omega$	--
Supply Current	--	9 mA	14 mA
Common Mode Rejection Ratio (CMRR)	--	110	--
Input Bias	--	1 pA	--



# MyoWare Electrodes

---

- Middle Electrode (1):
  - Placed in the belly of the muscle
- End Electrode (2):
  - Placed such that the length of the device is parallel to muscle fibers
- Reference Ground (wire):
  - Placed away from middle and end electrodes
  - Often placed on boney area near the muscle



# MyoWare Placement




Innervation Zone



Correct Placement



Midline Offset



Myotendon Junction

# Myoware Output: Rectified EMG Envelope

- Signal Processing done on board
- Output is an ADC friendly signal

Rectified & Integrated  
EMG Signal



# Myoware Output: Raw EMG Waveform

- New Myoware offers Raw EMG output (already amplified) from the board
- Enable user to do different signal processing techniques

RAW EMG Signal







## Reference:

“The ABC of EMG: A Practical Introduction to Kinesiological Electromyography”  
By Peter Konrad, Noraxon INC (2005).

“MyoWare™ Muscle Sensor (AT-04-001) DATASHEET”



# Thanks

## Q & A